



REMOVABLE PANEL STORM WINDOW OPERATING INSTRUCTIONS

To remove glass panel or screen insert from the master frame:

- 1.) Loosen the screws holding the panel clips with a Phillips screwdriver. Loosen so the panel clip rotates, but do not remove the panel clips.
- 2.) Rotate all panel clips so they are not in contact with the glass panel or screen insert.
- 3.) Grasp the lower lift rail. Pull the bottom of the glass panel or screen in until it clears the lower portion of the master frame. Lower the glass panel or screen until it clears the head.
- 4.) Some Mon-Ray removable panel's come with an interchangeable screen insert and glass panel. If your window has a screen, reverse the procedure you used to remove the glass panel, to install the screen.
- 5.) If you do not have a screen frame and would like one, contact your Mon-Ray authorized dealer.

To re-install glass panel and screen insert:

- 1.) Reverse the procedures for removing the glass inserts and screen listed above.

If you need assistance, please call us at **(800) 544-3646**.