



## DeVAC Model 470 Operating Instructions

### **To Open For Ventilation:**

- A. Grasp the cam handles and turn downward.
- B. Pull the sash inward to the desired ventilating position.

### **To Close:**

- A. Push the sash closed.
- B. Raise the cam locks upward to lock the sash in place.

### **A. Cleaning and inspection**

The sash can be easily washed from the interior.

1. Follow the operating instructions to open the window and then wash the exterior of the sash.
2. Follow the operating instructions for closing the window and then wash the interior of the sash.

### **Hinge adjustment**

If the sash floats and will not stay in place, there is a screw on the 4 bar hinge that can be tightened. Locate the screw and turn it in a clockwise direction until the sash stops floating.

If you have further service or operation questions contact Mon-Ray's customer service department at (800) 544-3436.

