



## DeVAC Model 480 Operating Instructions

### **To Open For Ventilation:**

- A. Grasp the Roto-operator and turn in a clockwise direction.
- B. Keep turning until the sash is at the desired ventilating position.
- C. Do not continue turning the Roto-operator after the sash is in the maximum open position because the Roto-operator could strip

### **To Close:**

- A. Grasp the Roto-operator and turn in a counter-clockwise direction.
- B. Keep turning counter-clockwise until the sash is closed tightly.
- C. Do not over tighten because the Roto-gears could strip.

### **Cleaning and inspection**

The inside of the window can be easily washed from the interior. To wash the exterior a squeegee and sponge must be used.

1. Follow the operating instructions to open the window and then wash the exterior of the sash. Slide the sponge through the space at the head of the sash and wash the glass. Squeegee off the glass.
2. Follow the operating instructions for closing the window and then wash the interior of the sash.

### **Hinge adjustment**

If the sash floats and will not stay in place, there is a screw on the 4 bar hinge that can be tightened. Locate the screw and turn it in a clockwise direction until the sash stops floating.

If you have further service or operation questions contact Mon-Ray's customer service department at (800) 544-3436.

